



A Roll-Rite Brand



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

513-0019: Dual Stage Pulltarp Tower



SuperShield™ 9500M



Open 9000M

Document #: 607-0115
Revised: 01/27/26 WLH

DURING INSTALLATION, SOME FABRICATION MAY BE REQUIRED.

1404 N. Marshall Ave. El Cajon CA. 92020 • For technical support call us at (877) 861-6265 or visit at Pulltarps.com.



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Table of Contents****Components**

Dual Stage Pulltarp Tower #513-0019	2
SuperShield™ 9500M 100" Tower Assembly with Tray #513-0082.....	3
Open 9000M 102" Tower Assembly with Tray #513-0073	4
Tower Tray Hardware Kit #501-0687 (Illustrations not to scale).....	5
105" Pullrod with Hardware #501-0420 (Illustrations not to scale)	6

Dual Stage Pulltarp Tower Systems

Mounting the Tower System	8
Hydraulic Pump Positioning	9
Installing the Hydraulic Pump.....	10-11
Attaching the Manual Control Box to the Tower	12-13
Connecting Control Box to Hydraulic Pump	14
Adding Hydraulic Fluid to Pump Reservoir	15
Installing Hydraulic Protective Cover.....	16

Ratchet & Rollertube Operation

Installing Tarp and Adding Spring Tension to Ratchet.....	18-19
Removing Spring Tension from Ratchet.....	20

Tower Operation

Extending & Retracting Tarp	22-24
-----------------------------------	-------

Tower Maintenance

Hydraulic Pack, Oil Levels & Filtration	26
Recommended Scheduled Maintenance	27
Hydraulic Pack Diagnostics	28
Motor Check Out Procedure	29




A Roll-Rite Brand



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower



COMPONENTS

1404 N. Marshall Ave. El Cajon CA. 92020 • For technical support call us at (877) 861-6265 or visit at Pulltarps.com.






INSTALLATION INSTRUCTIONS


Dual Stage Pulltarp Tower

Dual Stage Pulltarp Tower #513-0019



ITEM	PART #	DESCRIPTION	QTY
1	513-0080	Dual Stage Electric Tower	1
2	501-0687	Tower Tray Hardware Kit	1
3	514-9986	10' Pump Power Wire	1
4	501-0621	Steel Rope Hook Kit	1
5	517-1009	Pull rope 50' with Bungee	1
6	501-0420	105" Pullrod with Hardware Bag	1

REV. 09/28/18 WLH






INSTALLATION INSTRUCTIONS

Dual Stage Pulltarps Tower

ITEM	PART #	DESCRIPTION	QTY
1	501-0121	9.5" x 100" SuperShield™ Housing	1
2	501-0647	System End Plate Ratchet	1
3	501-0801	System End Plate Stud	1
4	501-1307	100" Spring Roller Tube	1
5	503-3101	5/16" - 18 x 1/2" Hex Bolt	12
6	503-3104	5/16" - 18 x 3/4" Carriage Bolt	4
7	504-3103	5/16" - 18 Nylock Nut Steel	16
8	504-5001	1/2" Crimp Nut	1
9	505-2502	1/4" USS Washer 5/16"	16
10	505-5001	1/2" AN Washer 1/16" Thick (Not Shown)	1
11	505-5002	Washer Nylon .51D x 1.250D	2
12	506-9937	10-32 x 5/8" Philips Pan Head Screw	4
13	513-0079	100" R/R Tower Tray	1
14	513-0090	Tower End Support Insert	2
15	607-0061	Pulltarps Decal for System	1

REV. 12/02/21 WLH




SuperShield™ 9500M 100" Tower Assembly with Tray #513-0082



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarps Tower

Open 9000M 102" Tower Assembly with Tray #513-0073



REV. 12/13/21 WLH



ITEM	PART #	DESCRIPTION	QTY
1	501-0647	System End Plate Ratchet	1
2	501-0801	System End Plate Stud	1
3	501-1369	102" Roller Assembly	1
4	503-3118	5/16" - 18 x 5/8" Carriage Bolt	16
5	504-3102	5/16" - 18 Thin Nylock Nut	16
6	505-2502	1/4" USS Washer 5/16"	16
7	505-5001	1/2" AN Washer 1/16" Thick (Not Shown)	1
8	505-5002	Washer Nylon .15D x 1.250D (Not Shown)	2
9	506-9937	10-32 x 5/8" Philips Pan Head Screw	4
10	513-0061	Tower Housing 102"	1
11	513-0062	Tower Housing End Plate	1
12	513-0072	Tower Ratchet End Plate	1
13	607-0061	Pulltarps Decal for System (Not Shown)	1



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Tower Tray Hardware Kit #501-0687 (Illustrations not to scale)



ITEM	PART #	DESCRIPTION	QTY
1	503-2501	1/4" - 20 x 1/2" USS Carriage Bolt	2
2	503-3103	5/16" - 18 x 3/4" HHCS Bolt	2
3	503-3717	3/8" - 16 x 3/4" Carriage Bolt	8
4	503-5020	1/2" - 13 x 1" Carriage Bolt	6
5	504-2503	1/4" - 20 USS Nylock Nut	2
6	504-3103	5/16" - 18 Nylock Nut Steel Zinc	2
7	504-3705	3/8" - 16 Nylock Nut "Thin"	8
8	504-5004	1/2" - 13 Nylock Nut	6
9	504-9903	10 - 32 Nylock Nut	4
10	505-2502	1/4" USS Washer 5/16" Hole	4
11	505-3702	Washer 3/8" SAE Flat Zinc	8
12	505-5004	1/2" USS Flat Washer	6
13	506-9905	10 - 32 x 1/2" Philips Pan Head Screw	4
14	513-0093	Universal Tower Switch Plate	1
15	514-9977	Wire Clamps 3/4" ID	2


REV. 09/13/18 WLH



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

105" Pullrod with Hardware #501-0420 (Illustrations not to scale)



ITEM	PART #	DESCRIPTION	QTY
1	501-0644	Tarp Guide Steel	2
2	501-1410	Reliance Sleeve	2
3	505-0201	Pullrod Washer 2-1/2"	2
4	506-2502	1/4" - 20 x 1" Slotted Hex	2
5	517-0106	1-1/4" Greay PVC	12
6	517-0606	105" Pullrod	1

REV. 10/08/18 WLH



A Roll-Rite Brand




INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower



DUAL STAGE PULLTARP TOWER SYSTEMS



1404 N. Marshall Ave. El Cajon CA. 92020 • For technical support call us at (877) 861-6265 or visit at Pulltarps.com.







INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Mounting the Tower System

Step 1: Mount the Tower Base onto the Frame Rails and leave at least 6" of space between Cab and Tower (Fig. 1). Verify there is enough space between Cab and Tower. Mount with Weld Brackets (Fig. 2) or U-Bolt Brackets (Fig. 3).



Step 2: With a team member, lift the Housing & Support Tray then place on top of Tower Base. Secure with the supplied hardware (Fig. 4A through 4D).

Note: Make sure the Tower Base is level and secured before mounting.






INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Hydraulic Pump Positioning

Step 3: The pump for the **SuperShield™ 9500M** can be mounted on either side of the tower for Driver access (Fig. 5). The pump for **Open 9000M** can also be mounted on either side of the tower for Driver access (Fig. 6).



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Installing the Hydraulic Pump**

Step 4: Secure the Hydraulic Pump to the corresponding side of the Tower Base using the supplied mounting hardware (Fig. 7A, B & C).



Step 5: Rotate the Hydraulic Connectors to face the tower (Fig. 8).

Note: Hydraulic fluid may leak when removing the caps at the end of each hose.



Step 6: Attach the first Hydraulic line, marked green and yellow, to the first connector (Fig. 9).

Note: Use a backup wrench when attaching Hydraulic line.



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Installing the Hydraulic Pump**

Fig. 10




Step 7: Attach the second Hydraulic line (Marked Red) to the second (outer) Hydraulic connector (Fig. 10).

Note: Use a backup wrench when attaching Hydraulic line.

Step 8: Check the lines to make sure there aren't any leaks from the Hydraulic lines (Fig. 11).

Fig. 11



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Attaching the Manual Control Box to the Tower**


Step 9: Shown below (Fig. 12A) is the The Mounting Plate installed without the Control Box. The Mounting Plate is engineered to hold four (4) different Control Systems (Fig. 12B).

Fig. 12A

**Control Box Mounting Positions (4 Mounting Holes for each)**

1. Roll-Rite Control Box (Electric Tower Only)
2. Smart Switch Control Box (Electric Tower Only)
3. Manual Control Box
4. Icarus Blue Tooth Control Box (Pending)

Fig. 12B





INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Attaching the Manual Control Box to the Tower

Step 10: Align the four (4) holes on the Control Box with the corresponding holes on the Mounting Plate (Fig. 13). See mounting guide in Step 9 for reference.

Fig. 13



Step 11: Place the mounting screws through the front of the Control Box, through the mounting plate and secure with a Nylock Nut. Use a wrench to hold the Nylock Nut in place while you tighten with a Philips Screw Driver (Fig. 14A-C).

Fig. 14A



Fig. 14B



Fig. 14C



Step 12: Place the mounted Switch on the Tower Mount (Fig. 15), see Step 3 for proper mounting position. Insert the Carriage Bolts from the back side of the Tower Mount (Fig. 16). Once all four (4) bolts and nuts are mounted, tighten securely onto the Tower (Fig. 17).

Fig. 15



Fig. 16



Fig. 17



Note: You may need an assistant to safely mount the Control Box.



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Connecting Control Box to Hydraulic Pump

Step 13: Once the Control Box is secured, take the end of the attached power cable and insert into wiring harness cover (Fig. 18).

Fig. 18



Step 14: Pull the wires through the other end of the wire cover hole. Make sure the full wire is pulled through (Fig. 19).

Fig. 19



Step 16: Connect Red Wire and Power Plug Wire with Blue Connector to Copper Bolt. Then place washer and nut on bolt and secure (Fig. 21A & B).

Fig. 21A



Fig. 21B



Step 17: Connect the Power Plug Ground Wire and Black Ground Wire to the positions shown (Fig. 22A). Securely tighten with nut (Fig. 22B).

Fig. 22A



Fig. 22B



Fig. 20A



Fig. 20B



Step 15: Take the White wire with the small Blue Connector and attach to the single bolt on the Distribution Box. Secure with washer and nut (Fig. 20A & B).

Fig. 23A



Fig. 23B



Step 18: Connect the Black and Green wires with the Pin Connectors to the Black Box next to the Distribution Box (Fig. 23A & B).

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Adding Hydraulic Fluid to Pump Reservoir**


**Dextron II ATF
or
32 Grade
Hydraulic Oil**

Fig. 24

Step 19: Fill pump reservoir with two (2) quarts of Automatic Transmission Fluid or 32 Grade Hydraulic oil (not supplied) (Fig. 24).

Fig. 25

Step 20: After filling, reinsert filler cap and secure. Check system for leaks (Fig. 25).

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Installing Hydraulic Protective Cover****Fig. 26**


Step 21: Facing the back of the Tower System, take the Hydraulic Case back panel and attach with supplied hardware (Fig. 26).

Fig. 27

Step 22: Take the second panel that is bent at two points and attach to the back plate and tower (Fig. 27).

Fig. 28

Step 23: Secure the Hydraulic Cover lid and remove any remaining tape (Fig. 28).

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower**



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarps Tower

Installing Tarp and Adding Spring Tension to Ratchet

Step 1: Align the Roller Tube groove with the Slot in the Housing (Opposite of the Ratchet Plate). Take the end of the tarp with the Hemtube and insert in to the system housing (Fig. 29).

Note: Make sure the Pulltarps logo is facing up.

Fig. 29




Step 3: Fully extend tarp and tie off on the Tailgate (Fig. 31).

Fig. 31



Step 2: Carefully slide the tarp through the Roller Tube groove until the tarp is centered.(Fig. 30).

Fig. 30



Step 4: Remove the Ratchet Lock Nut and Star Lock Washer (Fig. 32A, B & C).


Fig. 32A



Fig. 32B



Fig. 32C





INSTALLATION INSTRUCTIONS

Dual Stage Pulltarps Tower

Installing Tarp and Adding Spring Tension to Ratchet

Step 5: With the included Ratchet Wrench, turn the ratchet nut clockwise 35 - 40 winds (Fig. 33).

Note: Insert 3/8" bolt into Lock Nut hole for added safety.

Fig. 33



Step 6: Test the spring tension by having a team member hold the end of the tarp while the other team member removes the 3/8" bolt holding the Roller Tube in place. Let go of tarp while holding Pullrope, and if tarp returns to the housing, no more winds are needed. If more winds are needed, repeat Steps 3-5 then add 5 winds and test again (Fig. 34).

Fig. 34



Step 7: Reinstall the Ratchet Lock (Fig. 35A & B).

Fig. 35A



Fig. 35B



NOTE: Tarp must be fully extended when adding tension to the spring.



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarps Tower

Removing Spring Tension from Ratchet

Step 1: Remove the Ratchet Lock Nut and Star Lock Washer (Fig. 36A & B).

Fig. 36A



Fig. 36B



Step 2: Insert screwdriver to disengage lever (Fig. 37). Hold wrench and slowly unwind spring pressure (Fig. 38).

Fig. 37



Fig. 38



Step 3: When desired tension is achieved remove screwdriver, allowing release lever to reengage ratchet gear (Fig. 39A & B).


Fig. 39A



Fig. 39B



Fig. 40



Step 4: Reinstall the Ratchet Lock (Fig. 40).



A Roll-Rite Brand



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

TOWER OPERATION

1404 N. Marshall Ave. El Cajon CA. 92020 • For technical support call us at (877) 861-6265 or visit at Pulltarps.com.



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Extending & Retracting Tarp**

IMPORTANT: Thank you for purchasing your new Pulltarps Tower. Before you start using your new tower, please ensure that you carefully read and understand these instructions and make sure that you always operate this equipment in a safe manner.

WARRANTY: Pulltarps warrants that the products are free from defect in workmanship and material under normal and proper use and on condition that the machine has been used in accordance with the operating instructions. The warranty period is 12 months or time of operation corresponding to this, from the date the machine is installed by the customer.

The tarp itself is not guaranteed for tearing or wearing out; however, it is guaranteed against defects in workmanship and materials for a period of six months from the date of purchase.

Step 1: Raise tower as high as possible to keep tarp from dragging on the load in the container (Fig. 41). Ensure Pull Rope is untied and accessible.


Note: Never operate vehicle with tower extended.

Fig. 41



Step 2: Pull the tarp over the container past the tarp return ramps. When deploying and retracting, be sure there are no obstructions protruding from the box that will interfere with operation of the tarp system (Fig. 42).

Fig. 42





INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Extending & Retracting Tarp

Step 3: Pull the Pullbar past the Tarp Return Ramps, then slowly seat the Pullbar into the Tarp Return Ramps (Fig. 43).

Fig. 43



Step 5: Slowly lower the tower so that the tarp wraps neatly around the container (Fig. 45).

Fig. 45



Step 4: Secure the Pull Rope on the Rope Hooks at the end of the container (Fig. 44).

Fig. 44



Step 6: To retract the tarp, raise the tower completely, then pull the Pull Rope until the Pullbar clears the Tarp Return Ramps and let the spring tension retract the tarp into the housing. Flip the rope over the box towards the rope hooks on the front of the container (Fig. 46).

Fig. 46



**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Extending & Retracting Tarp**

Step 7: Lower tower completely (Fig. 47). After Tower is fully lowered, secure Pull Rope and Rope Hooks (Fig. 48).

Note: Never operate vehicle with tower extended.

Fig. 47



Fig. 48



WARNING: Never operate the vehicle with tower extended; it might cause serious injuries or damages.



A Roll-Rite Brand



INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

TOWER MAINTENANCE

1404 N. Marshall Ave. El Cajon CA. 92020 • For technical support call us at (877) 861-6265 or visit at Pulltarps.com.





INSTALLATION INSTRUCTIONS

Dual Stage Pulltarp Tower

Hydraulic Pack, Oil Levels & Filtration


Step 1: For maintenance purposes, you will have to separate tank from the power unit (Fig. 49A & B). Be sure to have O-ring installed before assembling again. Forgetting this step will cause fluid to gush out.

Note: There are 4 bolts and brackets in between valve block and tank.



Step 2: The level of oil inside the reservoir should be verified daily and topped up if necessary (Fig. 50).

If you see a change in the need to add oil to the system, there may be a system problem where oil is leaking from the hydraulic circuit.



Step 3: Each system comes equipped with a filtered filler-breather to help prevent foreign material from contaminating the hydraulic oil reservoir. Over time, the breather can become clogged and it should be replaced regularly. In addition, a suction strainer is mounted to the intake side of the hydraulic pump, and is located inside the reservoir (Fig. 51).

Note: The suction filter should be cleaned or replaced as part of a regular maintenance routine.

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Recommended Scheduled Maintenance****Daily Maintenance**

- Check hydraulic hoses for wear, tear and leaks.
- Check mechanism for any damage.
- Check tarpaulin for tears.
- Check if the system operates smoothly.

Weekly Maintenance

- Check mechanism for any excessive wear and tear.
- Check hydraulic hoses and components for leak and damage.
- Check arm spring tension.
- Check hydraulic fluid in power unit. Check the level with tower fully lowered, to top of the side indents.

Monthly Maintenance

- Verify the tightness of hydraulic fittings, do not over tighten.
- Verify the tightness of the fasteners.
- Check welds and other joins for cracks.
- Apply grease to inner stages.

Two Year Maintenance

- Clean and wipe tank.
- Flush out Oil.
- Replace Intake Strainer.

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Hydraulic Pack Diagnostics**

Power Pack won't lift load.	<ul style="list-style-type: none">Check fluid level. If there is not enough oil in the unit, you will not be able to operate the actuator.Gear Pump might not be priming. Remove relief valve, operate pump for a few seconds until fluid comes out of port, replace relief valve and rety unit (See Fig. 46).Air being introduces in system. If air is being introduced in the system, the gear pump might have some priming problems.
Motor not running.	<ul style="list-style-type: none">Check for power connection to DC Motor.Check power to start solenoid.Check connections at the battery.
Start solenoid just clicks, Motor not turning.	<ul style="list-style-type: none">Check for loose wire from start solenoid to DC motor.Make sure you use a minimum of 6 guage of wire from your battery to the unit.Check for cracked housing on start solenoid, if so, replace start solenoid.If an older unit, check for rust buildup inside DC motor.
Electric Motor will not stop running.	<ul style="list-style-type: none">Low battery or poor ground connection has caused the start solenoid to weld on. Replace start solenoid and check battery and ground. Ground must be connected directly to battery.
Excessive heat from unit.	<ul style="list-style-type: none">A bad electrical ground or poor battery performance will cause motor to generate more heat. Verify battery and ground for good performance.

**INSTALLATION INSTRUCTIONS****Dual Stage Pulltarp Tower****Motor Check Out Procedure**

1. Remove leads from motor and attach volt meter to leads
2. With the switch in the ON position, the volt meter should read 12 on 12 volt system and 24 on 24 volt system. If voltage is low, re-check with engine running and inspect wiring and connections (minimum 6 gauge wire must be used).
3. Return switch to the neutral position and reattach leads to motor.
4. Attach volt meter to leads at the motor.
5. With the switch in the ON position and the leads attached, the volt meter should read 10.5 on 12 volt system and 18.5 on a 24 volt system. If voltage is low, recheck with engine running. Recheck wiring and connections (minimum 6 gauge wire must be used).
6. Return switch to the neutral position and attach amp meter to leads at the motor.
7. With the switch in the ON position, the amp meter should read approximately 30 amps. A constant amperage reading of over 50 amps indicates binding in the system and/or low voltage.
8. Check 100 amp breaker for failure.

Fig. 52


**Power Wire Connections**

Figure 52 shows the proper wire connections.