



A Safe Fleet Brand



Installation Instructions

Pulltarps Bolt-On Mounting System

501-0611



CUTAWAY VIEW OF SUPERSHIELD™ 9500

(For use on all SuperShield™, Aluminator™, Steel Protector™ and Open Systems)

607-0156

WLH 08/02/19



A Safe Fleet Brand




TABLE OF CONTENTS

Parts & Tools		Installation Instructions	
Pulltarps Bolt-On Mounting System Tools	2	Setting the Location & Drilling Holes	5
Pulltarps Bolt-On Mounting System #501-0611.....	3	Attaching the Plus Nut	6
		Mounting the System	7



A Safe Fleet Brand



PARTS & TOOLS





A Safe Fleet Brand



Installation Instructions

Pulltarps Bolt-On Mounting System

Pulltarps Bolt-On Mounting System Tools



ITEM	DESCRIPTION	QTY
1	Permanent Marker	1
2	Customer Service Ratchet Tool	1
3	Standard Ratchet	1
4	Reversable Ratchet	1
5	Power Drill with Step Drill Bit	1
6	Power Drill with 1/2" Socket	1

REV. 07/31/19 WLH




A Safe Fleet Brand



Installation Instructions

Pulltarps Bolt-On Mounting System

Pulltarps Bolt-On Mounting System #501-0611



ITEM	PART #	DESCRIPTION	QTY
1	503-3106	5/16"-18 x 1.25 HHCS GR5	12
2	504-3109	5/16"-18 Plus Nut (Kit)	1
3	505-3102	5/16" Lock Washer	12
4	505-2502	1/4" USS Washer 5/16" Thick	12
5	501-0684	Customer Service Ratchet Tool	1

REV. 08/02/19 WLH



INSTALLATION INSTRUCTIONS



A Safe Fleet Brand






Installation Instructions

Pulltarps Bolt-On Mounting System


Setting the Location & Drilling Holes

Step 1: Placing system on box

Place the housing on the desired location on the vehicle (Fig. 1A & B).






Step 2: Marking mounting holes
Using a Sharpie, mark each mounting hole while system is in place (Fig. 2).



Step 3: Remove housing
Remove the housing and set aside (Fig. 3).

Step 4: Drilling the Holes

In the first mark, drill 31/64" hole with a Step Drill and clear off any debris. Repeat until all holes are drilled (Fig. 4A, B & C).



Step 5: Checking hole diameter
check the hole diameter is big enough to fit the Plus Nuts (Fig. 5).



Installation Instructions

Pulltarps Bolt-On Mounting System

Attaching the Plus Nut

Step 6: Assembling the Bolt and Washer

Place a washer (#505-2502) on the 1-1/4" Hex Bolt (#503-3106) and slide through the hole in the Customer Service Tool (#501-0684) (Fig. 6A & B).







Fig. 7A



Step 7: Attaching the Plus Nut

Twist the Plus Nut (#504-3108) on the other end of the bolt, so it matches up with the slot on the Customer Service Tool (#501-0684) (Fig. 7A & B).

Fig. 7B



Step 8: Attaching Plus Nut

Place the Plus Nut into the first hole and tighten using a ratchet or power drill. Tighten until nut is secured and flat on surface (Fig. 8A & B).





Fig. 9A





Fig. 9B



Step 9: Finish attaching the Plus Nuts

Unscrew the bolt and washer from the Plus Nut and repeat this process for the remaining holes (Fig. 9A & B).



Installation Instructions

Pulltarps Bolt-On Mounting System

Mounting the System

Fig. 10A





Fig. 10B



Step 10: Attaching Housing to Box.

Place the housing back in the original position, so the holes line up with the Plus Nuts (Fig. 10A & B).

Fig. 11A





Fig. 11B



Step 11:

Insert Bolts into Plus Nut

Place the Lock Washer (#503-3102) and Washer (#505-2502) on the Hex bolt (#503-3106) and hand-tighten into each Plus Nut (Fig. 11A & B).

Fig. 12



Step 12: Securing System to Box.

Tighten down all the Bolts with ratchet tool or Customer Service Tool, so that your system is safely secured and bolted onto the vehicle (Fig. 12).