


# Parts and Accessories



## Load Climber

Our patented Load Climber is a simple solution to keep the pullrod from digging into peaked loads. The Load Climber's rollers lift the tarp up over the load. The Load Climber can be easily added to your pullrod without modifying the tarp. For Pulltarps® and Electric Pulltarps® Systems only.

Part # 501-0901



## Tarp Tamer

When your system is mounted above the side rails, the Tarp Tamer's fixed roller holds the front of the tarp down to prevent material from blowing out. The Tarp Tamer can be used with Pulltarps®, Manual Arms, and Automatic Arm systems.

Part # 501-0701



## Open System Wind Guard

Protect the tarp from wind damage with the optional Wind Guard. Directs the wind up and over the tarp rather than under it. Simple installation and economical.

Part # 501-1001



## Aluminum Open System Wind Guard

The optional Wind Guard for Aluminum Open Systems protects the tarp from wind damage by directing the wind up and over the tarp. Simple installation and economical. Can be ordered with your system or added later as an upgrade.

Part # 501-10XX